




QuickTime™ and a
decompressor
are needed to see this picture.

In-Situ Plankton Imaging



Charles Cousin, M.S. eng.
President
Bellamare, LLC

Marina Murzina, Ph.D.
President & CTO
Traklogik Corporation

www.bellamare-us.com
info@bellamare-us.com
(858) 578-8108


www.traklogik.com
mm@traklogik.com
(760) 744-2845

Founded in 2006 to provide engineering services to the **University of Miami** Marine Biology Department



The goal was to design/manufacture a:

“In-Situ Plankton Imaging System”




Already Two Major Achievements:

Innovative Imaging System & Innovative ROTVs

Future Developments - Need for **less expensive, smaller systems** -
Skids to Rosette CTD, Hand Deployable Tow Fish, Smaller ROTVs

Replace / Complement Net Systems




Hard work & lots of microscope time...
2 days at sea = 1 man-year of microscope work!


Imaging is a great solution

- Precise location position and time of each organism
- Inform about spatial and vertical distribution of critters (fine-scale distributions of plankton from centimeter- to basin- wide volumes)
- Environmental data of the organisms' surroundings are sampled in sync.
- Imaging does not destroy organisms - easier to recognize!


Imaging “LARGE VOLUME OF WATER” (comparable to net tows)
Less abundant taxa is missed when imaging too small of a volume





Imaging tiny organisms at 5 knots...



ISIIS uses a **line-scan** camera.



It creates one single **CONTINUOUS image** representing a real “slice” of the ocean.



When put end to end,
images recorded represent
one continuous image,
several kilometers long,
matching the mission
profile.

▪ Plankton is the bottom of the ocean's **Food Chain** (No plankton, no fish, no whales....). It is also a very important part of the **Carbon Cycle**.

▪ **Climate Change / Pollution:** since plankton is not harvested or exploited by humans, adjustments in distribution and abundance can be attributed to changing environmental factors.

▪ **Fish Stocks:** the abundance of eggs and larvae is a scientific indicator of population abundance of adults.


Applications

Fundamental Science

High Frequency Monitoring of Fish Population

Coastal Construction Permitting / Environmental Monitoring

If high **data analysis** of collected images is **feasible**, we can **increase sampling frequency** which leads to **better monitoring** and leads to a greater capacity for **improved scientific inquiries**.



Automated Analysis is a Must!

QuickTime™ and a
decompressor
are needed to see this picture.


Generally, there are 2 necessary steps for pattern recognition:

Step 1. Segmentation :

find regions/objects of
interest (ROI-s)
versus background.

Step 2. Recognition :

identify objects of
interest as belonging to
certain classes.



Step 1. Segmentation for In-Situ High-Volume Imaging

Challenges:

Compared to Lab Imaging scanners (net tows → “Zooscan”), the background is real ocean water:

typical
zooscan image


- Non-uniform intensity distribution
- Bubbles
- Unrelated objects.

Compared to other In-Situ Imagers, we look at BIG water VOLUMES:


- Focus quality will vary!

typical VPR image:

focal plane



our system: VOLUME





Original


Mask

→ PROPRIETARY
SEGMENTATION
ALGORITHM →

Show Regions of
Interest (ROIs)



1. Data Reduction > 20 times.
2. Can be implemented on parallel hardware for real-time, on board, processing.
3. Number of ROIs and their distribution, by size, are already very informative!





original 300 Frames:
1.17 GB Total

segmentation

| Name | Size |
|-----------------------------|------|
| 002_016_co838_line1152.bmp | 3 KB |
| 002_025_co1325_line555.bmp | 6 KB |
| 002_037_co1826_line901.bmp | 3 KB |
| 003_003_co380_line374.bmp | 2 KB |
| 004_010_co598_line780.bmp | 2 KB |
| 004_027_co1893_line288.bmp | 2 KB |
| 005_023_co1207_line921.bmp | 2 KB |
| 006_012_co1045_line413.bmp | 4 KB |
| 006_020_co1288_line1758.bmp | 2 KB |
| 006_028_co1790_line1316.bmp | 2 KB |
| 007_012_co860_line640.bmp | 3 KB |
| 007_014_co969_line1896.bmp | 3 KB |
| 009_014_co846_line1592.bmp | 3 KB |
| 009_018_co1211_line1447.bmp | 3 KB |
| 010_027_co1861_line1064.bmp | 3 KB |

Regions of Interest:
57 MB Total





→ SEGMENTATION
ALGORITHM →

Further recognition must be adapted to non-perfect ROIs such as “group portraits” .

Recognition

Done manually, here, for
“Training” purposes




Step 2. Recognition

Ambiguities can be numerous...


Need to adapt Recognition to the imaging system's resolution:
Smaller, more abundant taxa should be imaged with a secondary system to avoid ambiguities.

Radiolarian type II

1mm



Jelly tiny




Chaetognath



Appendicularian



Shrimps



Fish



Known Plankton Recognition Approaches

- G. Tsechpenakis, C. Guigand, and R. Cowen, "Image analysis techniques to accompany a new In Situ Ichthyoplankton Imaging System (ISIS)", 2007.
- Q. Hu, C. Davis, "Accurate automatic quantification of taxa-specific plankton abundance using dual classification with correction", Marine Ecology Progress Series, 306: 51–61, 2006

Calculate 30+ features!!

size, aspect ratio, Hu moments, Fourier Coeffs for contour Radius(Angle), texture-based values (mean and range of co-occurrence matrices from different angles, energy, contrast, entropy, etc.) and a support vector machine classifier.

With extensive variety of plankton shapes, and potentially non-perfect ROIs (segmentation), generalization methods of recognition face a big challenge.


Our Approach is different...

Our Approach combines:

1) **Proprietary analytical methods** whenever there is a distinct recognition principle, like “triangular” copepods.
(includes integrating logical reasoning into distance equation in clustering space as logical polynomials)



2) CogniMem: **dedicated hardware** NN non-linear classifier:
learn and recognize a 256-bytes vector $< 11 \mu \text{ sec}$ @27MHz.



Publication on these results is coming...



Thank You!